



Typical plumbing schematic for solar / utility backup

All ball valves shown are for system charging and must be locked closed after system is charged.

JD/RD Feb 04

© 2003 BTF Ltd

extents, scale = 1/32", rot = 90, x = 4, y = 1